



Installation Instructions for 2019 Dodge Ram Exhaust System

Removal

1. Begin by placing a cut mark 1-1/4" to the rear of the factory muffler outlet. Using a Sawzall, hack saw, or cutting wheel, make a cut in the factory pipe at your mark.
2. Remove the bolts attaching the muffler to the front pipe, the grounding wire from the muffler, and the muffler wire hangers from the mounts.
3. You are now ready to remove the cut muffler section from the factory exhaust system.
4. Remove the gasket from the factory muffler inlet and **retain it for re-use**.



Installation

1. Begin by placing the clamp (included) on the outlet tube of your new B2 Fabrication muffler.
2. Install the B2 Fabrication muffler by bolting the system to the front flange with the retained factory gasket.
3. Be sure the newly placed exhaust system maintains a minimum clearance of 1/2" all around, while also being mindful of the suspension travel and vibration.
4. Aligned your tailpipes. It is helpful to have another person assist you with this step. When you are satisfied with the alignment of the tailpipe, tighten the supplied clamp to fix your new exhaust into place.

***That's it! You're done.
Enjoy your new Exhaust!***